



# CITROËN

ACT: 1252

Ref.9416.A9

## BOXER JUMPER

### Citroën VF7Y Peugeot VF3Y



= 0,20h

NOTICE DE POSE A USAGE PROFESSIONNEL  
FITTING INSTRUCTIONS FOR PROFESSIONAL FITTERS, INSTRUCCIONES DE MONTAJE PARA USO PROFESIONAL,  
MANUAL DE MONTAGEM PARA UTILIZACAO PROFISSIONAL, MONTAGEANLEITUNG FUR PROFESSIONNELLEN EINSATZ,  
ISTRUZIONI DI POSA AD USO PROFESSIONALE, MONTAGEHANDLEIDING VOOR PROFESSIONEEL GEBRUIK







